

## Steel Coupler

### SH



MODEL(T)

Hose Stem

SH 20

SH 30

SH 40

SH 400

SH 600

SH 800

### SM



MODEL(T)

Thread **R**

SM 20

SM 30

SM 40

SM 400

SM 600

SM 800

### SF



MODEL(T)

Thread **Rc**

SF 20

SF 30

SF 40

SF 400

SF 600

SF 800

### SN



MODEL(T)

Hose Nut(φT)

SN 08

SN 10

SN 12

### PH



MODEL(T)

Hose Stem

PH 20

PH 30

PH 40

PH 400

PH 600

PH 800

### PM



MODEL(T)

Thread **R**

PM 20

PM 30

PM 40

PM 400

PM 600

PM 800

### PF



MODEL(T)

Thread **Rc**

PF 20

PF 30

PF 40

PF 400

PF 600

PF 800

### PN



MODEL(T)

Hose Nut(φT)

PN 08

PN 10

PN 12

## Steel One - Touch Coupler

### OSH



MODEL(T)

Hose Stem

OSH 20

OSH 30

OSH 40

### OSM



MODEL(T)

Thread **R**

OSM 20

OSM 30

OSM 40

### OSF



MODEL(T)

Thread **Rc**

OSF 20

OSF 30

OSF 40

### OSN



MODEL(T)

Hose Nut(φT)

OSN 08

OSN 10

OSN 12