

Coupler BSBM

BSH



MODEL(T)

Hose Stem

BSH 20

BSH 30

BSH 40

BSM



MODEL(T)

Thread **R**

BSM 20

BSM 30

BSM 40

BSF



MODEL(T)

Thread **Rc**

BSF 20

BSF 30

BSF 40

BPH



MODEL(T)

Hose Stem

BPH 20

BPH 30

BPH 40

BPM



MODEL(T)

Thread **R**

BPM 20

BPM 30

BPM 40

BPF



MODEL(T)

Thread **Rc**

BPF 20

BPF 30

BPF 40

Mold Coupler BSBM

KSH



MODEL(T)

Hose Stem

KSH 20

KSH 30A

KSH 30

KSM



MODEL(T)

Thread **R**

KSM 10

KSM 20

KSM 30

KSF



MODEL(T)

Thread **Rc**

KSF 10

KSF 20

KSF 30

KPH



MODEL(T)

Hose Stem

KPH 20

KPH 30A

KPH 30

KPM



MODEL(T)

Thread **R**

KPM 10

KPM 20

KPM 30

KPF



MODEL(T)

Thread **Rc**

KPF 10

KPF 20

KPF 30