

1 BEFORE USING THIS PRODUCT


CW Configurator is a dedicated software package used for the parameter settings and monitoring of a C Controller module. The usability is much better since the functionality and appearance have been improved compared to existing Setting/monitoring tools for the C Controller module.

1.1 Main Functions of CW Configurator

CW Configurator manages module configuration data and parameters in project units in a C Controller module. CW Configurator has the functions shown below.

Parameter setting function

Parameters for C Controller modules, I/O modules, and intelligent function modules can be set.



Writing to PLC/Reading from PLC function

Set parameters can be written to or read from a C Controller module with the 'Write to PLC' function or the 'Read from PLC' function.

