

Keys and torque wrenches



Key (mm/inch)

Ordering code	mm	inch
170.3-860	2.5	
170.3-861	3	
170.3-864	2	
174.1-862	1.5	
174.1-863	2.5	
174.1-864	3	
174.1-870		5/64"
174.1-871		1/8"
174.1-872		3/16"
174.1-873		1/4"
265.2-815	2.5	
265.2-817	3	
265.2-818		1/8"
265.2-821	4	
3021 010-025	2.5	
3021 010-030	3	
3021 010-040	4	
3021 010-050	5	
3021 010-060	6	
3021 010-080	8	
3021 010-100	10	
3021 010-120	12	
3021 010-140	14	
3021 010-170	17	
3021 011-140		1/4"
3021 011-316		3/16"
3021 011-380		3/8"
3021 011-516		5/16"
3021 011-532		5/32"
3021 011-732		7/32"
3021 011-764		7/64"
3021 011-916		9/16"
3021 012-013	1.3	
3021 012-015	1.5	
3021 013-080	8	
5680 010-01	3.5	
5680 010-02	2.5	
5680 010-03	10	
5680 010-04	12	
5680 010-05	3	
5680 010-06	4	
5680 012-02	2	
5680 017-04	5	

Key (mm/Torx Plus)

Ordering code	(mm)	(Torx Plus)	(Torx Plus)
5680 041-03		06IP	
5680 042-03		30IP	
5680 043-10		08IP	
5680 043-11		09IP	
5680 043-12		10IP	
5680 043-13		15IP	
5680 043-14		20IP	
5680 043-15		25IP	
5680 043-16		27IP	
5680 043-17		30IP	
5680 043-18		50IP	
5680 043-19		55IP	
5680 048-01		15IP	
5680 048-02		10IP	
5680 048-03		20IP	
5680 048-04		20IP	
5680 048-05		25IP	
5680 048-06		25IP	
5680 048-07		30IP	
5680 049-01	3.5	15IP	
5680 049-02	4	15IP	
5680 049-03	3.5	09IP	
5680 049-04	3.5	10IP	
5680 049-05		15IP	10IP
5680 051-01		06IP	
5680 051-02		07IP	
5680 051-03		09IP	



Screwdriver

Ordering code	(Torx Plus)
416.1-864	15IP
5680 046-01	8IP
5680 046-02	15IP
5680 046-03	7IP
5680 046-04	9IP
5680 046-05	10IP
5680 046-06	20IP
5680 046-07	25IP
5680 046-08	6IP